





When placing or answering a call, simply use the set as you would an ordinary telephone. Follow these few steps to take advantage of its 2 line/2 hold features:

If you have more than one telephone and a line is already in use when you pick up the handset, just twist the line button to the other line to make or answer your call. To answer an incoming call when you are already using the 2 line/2 hold telephone, or to make a second call without disconnecting the first, follow these steps:



- Pull up the hold plunger. Let go. It'll stay up.



- Turn the line button to the alternate position.

- Speak to the second caller or place your call.

You may switch from call to call by turning the line button to either line as often as you like as long as the plunger is up.

Or someone may take either call on an extension phone. Once the extension party and the outside party are connected and once you've turned the line button to the line you wish to speak on, depress the hold plunger. This releases the other line from hold so the person on the extension can hear and be heard.

If your 2 line/2 hold telephone is equipped for signaling, you may sound the bell or buzzer connected to another inside phone by pushing the line button in. This signal can cue someone to pick up the phone, to come to you, or to perform some other task. The line button may be turned to either position when you depress it. Pressing the line button doesn't affect answering or placing calls, calls in progress or calls on hold.

To end a call on one line, move the line button to the other line and return the hold plunger to the normal position. Hanging up the handset terminates all calls and returns the hold plunger automatically.

TURN BUTTON







The 2 line/2 hold telephone is manufactured by Western Electric for the Bell System.



THE TRIMLINE® phone . . . Small, stylish, and so modern . . . Fits as comfortably in your hand as it does in your home . . . Available in a wide range of appealing colors in desk and wall models.

THE CARD DIALER telephone allows you to dial frequently called numbers automatically. Simply insert the appropriate card and touch the start bar. Available in single-line or multiline models.





SIB 2430B