

KS-19245, LIST 1
TELEPHONE ANSWERING SET
MECHANICAL ADJUSTMENT AND MAINTENANCE

1. GENERAL

1.001 This addendum supplements Section 514-155-300, Issue 3. Place this pink sheet ahead of Page 1 of the section.

1.002 This addendum is reissued to revise paragraphs 15.03 and 15.04.

1.003 Issue 1 of this addendum was issued to:

- Revise 2.03
- Add 2.04
- Revise 3.02

2. CHANGES TO SECTION

ISSUE 1 CHANGES

2.001 On Page 2, change paragraph 2.03 as follows.

2.03 *IN-USE Lamp E2 (All Sets):*

- (1) Remove top cover (2.01).
- (2) Remove List 5 amplifier (3.03).
- (3) Pull out and hold spring clip, if present, on side of lamp socket and remove lamp E2 (Fig. 4).
- (4) Replace lamp E2, List 5 amplifier, and top cover.

2.002 On Page 2 add paragraph 2.04 as follows.

2.04 *AUTO-ANS Lamp E3 (All Sets):*

- (1) Remove top cover (2.01).

(2) Remove ENA relay (3.04).

(3) Pull out and hold spring clip, if present, on side of lamp socket and remove lamp E3 (Fig. 4).

(4) Replace lamp E3, ENA relay and top cover.

2.003 On Pages 2 and 3 change paragraph 3.02 as follows.

3.02 *KS-19245, List 3 Recorder:*

- (1) Remove top cover (2.01).
- (2) Remove List 6 cartridge (6.01).
- (3) Remove four screws and remove side cover (Fig. 7).
- (4) Remove three retaining screws (Fig. 2) located on the bottom of the set.



Do not lift or pry on the trim plates (Fig. 3).

(5) Firmly grasp chassis of List 3 recorder and carefully withdraw until plug-in receptacle is disengaged (Fig. 4).

(6) Carefully move recorder toward rear of set to clear plastic MESSAGE INDICATOR DIAL (Fig. 9) and remove recorder from set.

(7) Plug new recorder into the plug-in receptacle (Fig. 4).

(8) Replace and tighten the three retaining screws.

NOTICE

Not for use or disclosure outside the
Bell System except under written agreement

- (9) Replace List 6 cartridge (6.02).
- (10) Replace side and top covers.

ISSUE 2 CHANGES

2.004 On Page 9 change paragraph 15.03 as follows.

15.03 ON-OFF (medallion) lamp lighted. Check following if otherwise:

- Function selector—Any position other than OFF
- Power cord properly installed
- Fuse not blown

Danger: Disconnect power cord before checking fuse.

- List 6 cartridge properly installed
- Lamp bulb.

2.005 On Pages 9 and 12 change paragraph 15.04 as follows.

15.04 Functions (Preliminary Check).

A. Announcement Record and Announcement Check

Following conditions should exist:

- Function Selector—ANN-REC or ANN-CHECK position
- ON-OFF (medallion) lamp lighted
- Forward limit switch on List 3 recorder not operated.