# INTERPHONE SYSTEM—1A HOME 2752-TYPE TELEPHONE SETS

## **CONNECTIONS AND MAINTENANCE**

#### 1. GENERAL

- 1.01 This section contains conversion and connection information for the 2752-type telephone set for use with 1A home interphone in conjunction with 3-type speakerphone. Connection information is also given for home interphone without speakerphone feature, but in such cases, it is recommended that the 2754-type telephone set be used.
- 1.02 This section is reissued to change section references in 3.01.
- 1.03 Operation with the 1A home interphone system requires installation of a 664B transmitter (ordered separately, Fig. 1).



The loudspeaker circuit is controlled by the speakerphone control unit. With speakerphone OFF the speaker is connected to the interphone circuit; with speakerphone ON the speaker is transferred to the speakerphone circuit.



The 3A cord reel shall be used when the telephone set is subjected to temperatures below 40 degrees F. The 3B cord reel shall be used when the telephone set is not subjected to temperatures below 40 degrees F.




Fig. 1-664B Transmitter Installed

- Table E—Conductor Assignments Using 75A
  Connecting Block or A25B Connector
  Cable
- Fig. 2—2752-Type Telephone Set Connections, Wired For 1A Home Interphone
- Fig. 3—2752-Type Telephone Set, Connections To 1A Home Interphone and 3-Type Speakerphone

### 2. CONNECTION INDEX

- Table A—Conversion of Telephone Set For 1A Home Interphone
- Table B-Pickup-Signal Key Conversion
- Table C-Ringer or Buzzer Connections
- Table D-Disconnecting Speakerphone Feature

## 3. MAINTENANCE

- 3.01 ♦ Refer to Division 502 for maintenance information for the 2752-type telephone sets. Refer to Division 512 for home interphone system requirements and maintenance information. •
- **3.02** Maintenance of the home interphone components of these sets (Fig. 1) is limited to replacement of defective units.

© American Telephone and Telepraph Company, 1970 Printed in U.S.A.

Page 1

TABLE A

CONVERSION OF TELEPHONE SET FOR 1A

HOME INTERPHONE\*

TEL SET	LEADS	REMOVE FROM	CONNECT TO	
Tel	(G-BK)	5R	1	
Set	(BK-G)	5 <b>T</b>	2	
Plug	(BR-BK)	+	DC2	
Key	(BR-BK)	X	4T	
00411	(W)		1	
664B TRMTR	(R)		2	
(Added)	(S)		DC1	

<sup>\*</sup> Convert 5th pickup key to signal (for door answering).

TABLE B
PICKUP-SIGNAL KEY CONVERSION

CONVERSION	635A2 KEY LEADS					
OPTIONS	(Y-BR)	(BR)	(BR-BK)			
HPPPP(1)S(A)	М	М	4T			
HPPSP(1)S(A)	M	SG	4T			
HPSSP(1)S(A)	SG	SG	4T			
HPP*S*P(1)S(A)	3H	SG	4T			

P(1)—Home interphone pickup key S(A)—Door answering signal key

\* See Note 2
Notes:

- Convert 5th pickup key to signal (nonlocking) for door answering by removing the P-28E773 locking pin from plunger.
- This option uses 2nd pickup key for private or intercommunicating line and 3rd key converted to signal.

TABLE C
RINGER OR BUZZER CONNECTIONS

						LEADS			D.B.
OPTION		RINGER					STRAP	BUZZER§	
	(R)	(BK)	(S-R)	(5)	(BL)	(R)	40		
Bridged Ringer on any Line		K	T*	†	+	+	A to R*	SCO.	
Common or Private Line Ringer or Buzzer	With Capacitor	K	RT	†	†	†	A to RR‡	MET TO	
	Without Capacitor	A	RT	†	†	†	A to RR‡	RR‡	RT
Ringer Permanently Silenced		K	K	+	+	†	A to K		

<sup>\*</sup>Terminal of line involved.

<sup>†</sup> Stored location.

<sup>†</sup>Insulated and stored.

<sup>‡</sup>RR terminal on terminal board.

<sup>§</sup>Connect buzzer in place of ringer using twisted pair station wire.

TABLE D
DISCONNECTING SPEAKERPHONE FEATURE (See Note)

	TEL SET COMPONENT LEADS				SPEAKERPHONE COMPONENT LEADS					
Conductor color	TEL SET PLUG			DIAL	SWITCH ASSEMBLY			PRINTED WIRING BOARD		
	(V-G)	(G-V)	(V-S)	(V)	(Y-BL)	(BL-Y)	(O-Y)	(Y-O)	(S-Y)	(S-BK
Disconnect from*	T1	R1	AG	7	S	F1	P1	M2	M2	M1

<sup>\*</sup>Terminals on telephone set terminal board.

**Note:** When speakerphone feature of set is not required but set is multipled with a set providing speakerphone operation, disconnect, insulate and store these leads to avoid interference with working circuits. If interference continues, disconnect leads at multipling point as near as possible to speakerphone control unit.





Fig. 2—2752-Type Telephone Set Connections (Sheet 1 of 3)



#### NOTES:

- I. REFER TO APPROPRIATE SECTION IN DIVISION 502 FOR EXCLUSION SWITCH CONNECTIONS IF REQUIRED.
- 2. CONNECT 664B TRANSMITTER (ORDERED SEPARATELY) AS SHOWN IN TABLE A.
- 3. [ ] DENOTES 3A CORD REEL LEAD COLORS.
  ( ) DENOTES 3B CORD REEL LEAD COLORS.

- \* INSULATED AND STORED
- T NOT USED IN HOME INTERPHONE SYSTEM
- O TERMINAL WITH SCREW
- O TERMINAL WITHOUT SCREW

Fig. 2—2752-Type Telephone Set Connections (Sheet 2 of 3)





Fig. 2—2752-Type Telephone Connections (Sheet 3 of 3)



- I. INTERCONNECTIONS MAY BE MADE USING AN A25B CONNECTOR CABLE WHEN THE 5IA AND 55-TYPE CONTROL UNITS ARE LOCATED AT THE KEY EQUIPMENT.
- 2. CONNECT R24 AS SHOWN WHEN ONLY ONE 730A RECEIVER IS USED. 3. SPEAKER LEADS MUST BE CONNECTED AS SHOWN FOR COMMON SYSTEM USE.
- 4. MUST BE CONNECTED TO A! WHEN USED WITH IAI OR IA2 KEY TELEPHONE SYSTEM
- 5. IF SPEAKERPHONE FEATURE IS NOT PROVIDED, CONNECT SPEAKER LEADS FROM 51A CONTROL UNIT DIRECT TO 75A CONNECTING BLOCK (TERMINALS 35 AND 36); DISTEGARD ALL CONNECTIONS SHOWN FOR 55-TYPE CONTROL UNIT.

  ② TERMINAL WITH SCREW
- O TERMINAL WITHOUT SCREW
- THE 55A CONTROL UNIT MUST BE MODIFIED FOR USE WITH THE TOUCH-TONE  $^{\textcircled{R}}$  following the code.

Fig. 3—2752-Type Telephone Set, Connections to 1A Home Interphone and 3-Type Speakerphone

TABLE E

CONDUCTOR ASSIGNMENTS USING 75A CONNECTING BLOCK OR A25B CONNECTOR CABLE

TELEPHONE SET CONNECTIONS				B CONNECTOR CAR	75A CONNECTING BLOCK		
LEAD DESIG.	PLUG PIN NO.	TEL SET TERMINAL	PAIR NO.	CONNECTOR PIN NO.	CONDUCTOR	TERMINAL NO.	IW CABLE
Т	26	IT		26	W-BL	1	W-BL
R	1	· IR		1	BL-W	2	BL-W
A or H	27	1H	0	27	W-()	3	W-()
Al or B	2	I IB	2	2	()-W	2	()-W
LGI	28	(1)†		28	W-G	5	W-G
LI	3	(1)†	3	3	G-W	6	G-W
T	29	2T		29	W-BR	7	W-BR
R	4	2R	4	4	BR-W	8	BR-W
A, H, or S	30	211		30	W-S	9	I W-S
В	5	‡	5	5	S-W	10	S-W
LG2	31			31	R-BL	11	R-BL
1.2	6	(2)†	- 6	6		12	BL-R
T	1	(2)†			BI_R	13	1 R-()
R	32	3T	7	32	R-()		O-R
	ī	3R		7	()-[]	14	
A. H, or S	33	3H	8	33	R-G	15	R-G
В	8	1		8	G-R	16	G-R
LG3	34	(3)†	9	34	R-BR	17	R-BR
L3	9	(3)†		9	BR-R	18	BR-R
2T	35	4T	10	35	R-S	19	R-S
213	10	4R	10	10	S-R	20	S-R
None	36	411	11	36	BK-BL	21	BK-BL
Spare	11	1	1.1	11	BL-BK	22	BL-BK
None	37	(4)†	12	37	BK-()	23	BK-()
None	12	(4)†	12	12	O-BK	24	()-BK
M2	38	2	13	38	BK-G	25	BK-G
MI	13		1.5	13	G-BR	26	G-BK
SII.	39	5H		39	BK-BR	27	BK-BR
DC	14	DC2	14	14	BR-BK	28	BR-BK
None	4()	(5)†		40	BK-S	29	BK-S
None	15	(5)†	15	15	S-BK	30	S-BK
S	41	S		41	Y-BL	31	Y-BL
FI	16	FI	16	16	BL-Y	32	BL-Y
MI	12	MI		12	Y-)	3.3	Y-()
PI	17	Pi	17	17	()-Y	34	()-Y
SP2	43	S2		43	Y-(i	35	Y-G
SPI	18	81	18	18	G-Y	36	G-Y
BL	1 11	BL		10	Y-BR	37	Y-BR
G or SG	19	SG	19	19	BR-Y	38	BR-Y
B or B1		RT			Y-S	39	Y-S
R or R1	45		20	45			S-Y
	20	RR		20	S-Y	4()	V-BL
T	46	ET	21	46	V-BL	41	
R	21	ER		21	BL-V	42	BI-V
A or H	47	EH	22	47	V-()	43	V-0
В	22	EB		22	()-V	44	O-V
TI	48	TI	23	48	V-G	45	V-G
RI	23	Ri		23	G-V	46	G-V
IT	49	8	24	49	V-BR	47	V-BR
IR	24	7	2,	24	BR-V	48	BR-V
AG	5()	AG	25	50	V-S	49	V-S
112	25	M2	20	25	S-V	50	I S-V

<sup>\*</sup> Terminate spade-tipped conductors of D50AA-3 mounting cord on the 75A connecting block as indicated.

Page 8 8 Pages

<sup>†</sup> Numbers in parentheses denote connections to LG and L terminals of key plugs as follows: (1)-Blue, (2)-Orange, (3)-Green, (4)-Brown, (5)-Slate.

Insulated and stored.